

**Spare parts list for 9100-HEU**

003	Ash Chamber Front Panel	300	Drawer caster
008	Oven Door	301	Drawer caster tap
008A	Pipe	304	Centring screw
008B	Holder	504	Deep Frier
008C	Handrail Tap	518	Frier
008D	Handle Tap	520	Springy Nut
008E	Glass Panel with Thermometer	528	Top roll
008F	Glass Panel	619	Upright Front Panel
008G	Glass Panel Washer	800	Heat Interchanger
008H	Oven Door Front Panel	804	Heat Shield
013	Hob Top Frame (steel)	804A	Insulation
021	Plug (plastic)	804B	Insulation
022	Side Panel (enameled to part)	813	Combustion Chamber Front Panel
023	Side Panel with Chimney Outlet (enameled top part)	821	Handle with Hook, set
024	Chimney Outlet Cover (top part)	821A	Holder II.
025	Chimney Outlet Cover (middle part)	821B	Pin
030	Ribbon	821C	Handle
034	Hand Rail Tube	869	Base for Oven Heating Controller (cast iron)
035	Sweep Opening Cover (middle part)	899	Grating Controller
040	Sweep Opening Cover (top part)		
043	Ash Reciever		
052	Drawer		
052A	Drawer Front Panel		
052B	Drawer Handle		
053	Ribbon		
054	Blinding Cover		
057	Grating Base (with metal plates)		
058	Rotatable Grating (cast iron)		
060	Upper Grating (cast iron)		
061	Head (cover for chamot part)		
062	Circlet collet (cast iron)		
063	Circlet (cast iron)		
064	Hob top II., set (steel)		
065	Hob top circle lid (cast iron)		
066	Body of the hob top (cast iron)		
068	Oven heating control pull		
071	Oven heating control (cast iron)		
076	Firehook		
077	Head metal panel		
085	Chamot part 1		
086	Chamot part 2		
087	Anchorage (metal panel part)		
088	Chamot part 4		
090	Chamot part 6		
091	Chamot part 7		
098	Isulation cord for hob top frame		